


Zen Pod Essential

Manual för vred



Belysning

Ljuset justeras med hjälp av en steglös dimmer på det övre vredet. Byt mellan lägen genom att trycka in ljusreglaget.

- **Small** Endast släpljuset går att justera.
- **Medium** Läge 1: släpljus, läge 2: mittljus.
- **Large** Läge 1: släpljus, läge 2: mittljus.




Ventilation

Fläkten justeras i tre lägen på det nedre vredet.

- Genom att vrida medsols ökar fläkten ett läge.
- Genom att vrida motsols minskar kapaciteten ett läge.

Zen Pod Advanced

Manual för vred



Belysning

Ljuset justeras med hjälp av en steglös dimmer på det övre vredet. Byt mellan lägen genom att trycka in ljusreglaget.

- **Small** Endast släpljuset går att justera.
- **Medium** Läge 1: släpljus, läge 2: mittljus, läge 3: spotlight.
- **Large** Läge 1: släpljus, läge 2: mittljus, läge 3: spotlight.




Ventilation

Fläkten justeras i tre lägen på det nedre vredet.

- Genom att vrida medsols ökar fläkten ett läge.
- Genom att vrida motsols minskar kapaciteten ett läge.

Zen Pod Essential

Knob manual



Lighting

The light is adjusted using a stepless dimmer on the upper knob. Switch between modes by pressing in the light control.

- **Small** Only the trailer light can be adjusted.
- **Medium** Mode 1: trailing light, mode 2: center light.
- **Large** Mode 1: trailing light, mode 2: center light.




Ventilation

The fan is adjusted in three positions on the lower knob.

- By turning clockwise, the fan increases one position.
- By turning counter-clockwise, the capacity decreases a position.

Zen Pod Advanced

Knob manual



Lighting

The light is adjusted using a stepless dimmer on the upper knob. Switch between modes by pressing in the light control.

- **Small** Only the trailer light can be adjusted.
- **Medium** Mode 1: trailing light, mode: 2 center lights, mode 3: spotlight.
- **Large** Mode 1: trailing light, mode: 2 center lights, mode 3: spotlight.



Ventilation

The fan is adjusted in three positions on the lower knob.

- By turning clockwise, the fan increases one position.
- By turning counter-clockwise, the capacity decreases a position.